

LFP + Format <i>Tetenal Spectra Jet Medien</i>	Epson Photo R2880	
Office	Tinte	Mirage Basis Medium
Duo Print 130 g Duo Print 176 g Archival Matt 230g	Matte Black Matte Black Matte Black	Double-Sided Matte Paper Double-Sided Matte Paper Epson Archival Matte Paper
Duo Print 130 g Duo Print 176 g Archival Matt 230g	Photo Black Photo Black Photo Black	Plain Paper Plain Paper Plain Paper

Photo	Tinte	Mirage Basis Medium
Glossy 200 g Glossy 272 g Satin 270 g Silk 290 g	Photo Black Photo Black Photo Black Photo Black	Epson Glossy Epson Premium Glossy Epson Premium Semigloss Epson Premium Luster Photo Paper

Premium	Tinte	Mirage Basis Medium
Glossy 310 g Pearl 310 g Baryta 310 g	Photo Black Photo Black Photo Black	Epson Premium Glossy Epson Premium Luster Photo Paper Epson Premium Semigloss

Information:

Um nicht empfohlene Medientypen freizuschalten wählen Sie bitte in Mirage:
"Einstellungen", den Reiter "Erweitert" und setzen bei "Nicht empfohlene Medientypen freischalten" einen Haken.