

LFP + Format <i>Tetenal Spectra Jet Medien</i>	Epson Stylus Pro 4900		
Format - Sheet	Tinte	Mirage Basis Medium	Epson 4900 - Druckerdisplay
Duo Print 130 g	<b>Matte Black</b>	Epson Enhanced Matte Paper	Enhanced Matte
Duo Print 176 g	<b>Matte Black</b>	Epson Enhanced Matte Paper	Enhanced Matte
Archival Matt 230 g	<b>Matte Black</b>	Epson Archival Matte Paper	Archival Matte
Glossy 200 g	Photo Black	Epson Premium Glossy Photo Paper 170	Premium Glossy 170
Glossy 270 g	Photo Black	Epson Premium Glossy Photo Paper 250	Premium Glossy 250
Satin 270 g	Photo Black	Epson Premium Semiglossy Photo Paper 250	Premium Semigloss 250
Glossy 310 g	Photo Black	Epson Premium Glossy Photo Paper 250	Premium Glossy 250
Silk 290 g	Photo Black	Epson Premium Luster Photo Paper 260	Premium Luster 260
Pearl 310 g	Photo Black	Epson Premium Luster Photo Paper 260	Premium Luster 260
Baryta 310 g	Photo Black	Epson Premium Semimatte Photo Paper 260	Premium Semimatte 260

Rollenware - LFP	Tinte	Mirage Basis Medium	Epson 4900 - Druckerdisplay
Glossy Paper 272 g	Photo Black	Epson Premium Glossy Photo Paper 250	Premium Glossy 250
Semi Matt Paper 240 g	Photo Black	Epson Premium Semimatte Photo Paper 260	Premium Semimatte 260
HD Glossy Paper 260g	Photo Black	Epson Premium Glossy Photo Paper 250	Premium Glossy 250
HD Satin Paper 260 g	Photo Black	Epson Premium Luster Photo Paper 260	Premium Luster 260
Premium Silk Paper 290 g	Photo Black	Epson Premium Luster Photo Paper 260	Premium Luster 260
Premium Lustre Paper 310 g	Photo Black	Epson Premium Luster Photo Paper 260	Premium Luster 260

**Information:**

Um nicht empfohlene Medientypen freizuschalten wählen Sie bitte in Mirage:

"Einstellungen", den Reiter "Erweitert" und setzen bei "Nicht empfohlene Medientypen freischalten" einen Haken.